SCENES-N-NATURE[®] CONTOUR SHEET[™] PLASTER NT6165



INSTRUCTIONS

IMPORTANT: Prepare using a clean bowl and utensils. Do not clean utensils in sink or pour excess plaster down drain.

Working Time: 20 minutes

Mixing ratio (approximately): 2.5-parts plaster to 1-part water (by volume)

1. Pour Contour Sheet Plaster slowly into cold water. Let stand for 2 minutes, then stir thoroughly for 1-2 minutes. As a starting point, mix 8 oz plaster with 3 oz water to cover an area approximately 12" wide x 12" long x 1/8" deep.

TIP! Mix the plaster for a consistency that is appropriate to the application. Adjust plaster to water ratio for a thicker or thinner consistency. More water yields a thinner mixture.


Mix a thinner consistency when:

• the plaster needs to be spread easily, such as when covering large areas (that are not weight bearing) OR when there are a lot of crevices

Mix a thicker consistency when:

- · applying to vertical surfaces so that the plaster doesn't run and pool
- an area of the Contour Sheet will bear weight (thicker mixtures yield stronger surfaces)
- there is a weak point due to shape, such as a 90° angle, or a seam
- 2. Mist Contour Sheet (NT6154-NT6159) or plaster surface with water, then pour or brush on plaster mixture.
- Let dry 24 hours before coloring with Terrain Base Colors (NT6185-NT6186) or Rock Color System Pigments (NT6177-NT6184).

Times are approximate and may vary due to environmental conditions.



Conforms to ASTM D4236

Made in USA